

MultiRIP

Setting Your Default Printing Settings

For those people that typically do the same type job over and over, MultiRIP gives you the ability to set your printing preferences for all the different settings found in the Printer Preference screens. Below are the written steps and a video for how to set your own preferences. Please refer to the MultiRIP Manual for screen shots of these instructions.

Steps to Setting Your Printing Preferences

1. Click on the Start Menu and go to Printers & Faxes Folders.
2. Right click on MultiRIP Stylus Pro 4800 icon and go to "Preferences".
3. Click on the Advanced Button at the bottom right corner of the Layout tab.
4. Set up the defaults for any of the selections listed. Some of the common settings are the following:
 - Page Size
 - RGB Source Profile
 - Ink Type
 - Media Type
5. Click Apply and Save Changes buttons.
6. Back in the Printers & Faxes window, right click on the MultiRIP Stylus Pro 4800 icon and go down to Properties.
7. Go the tab for Device settings. Make sure that the Paper Tray selection is the same size as selected in Step #4. Save changes.