

# MultiRIP

## How to Load the Inks in the Correct Printer Slots

Below is the key / legend for what slots you would put the dye sublimation ink and the MultINK inks into on your printer. The general rule is the CMYK channels get the dye sublimation ink (except for the 1400 version) and the LcLmLkLl channels get the heat transfer ink. Please note that some printers have the ink channels on different sides of the printers. Please verify where the ink channels are before loading any ink.

### Epson 1400 Printer Ink Layout

- 1 Black = Dye Sub or Heat Transfer Black
- 2 Cyan = Dye Sub or Heat Transfer Cyan
- 3 Magenta = Dye Sub or Heat Transfer Magenta
- 4 Yellow = Dye Sub or Heat Transfer Yellow
- 5 Light Black = MultINK Black (for film positive printing only)
- 6 Light Cyan = MultINK Black (for film positive printing only)

**NOTE:** Please check with your distributor to make sure that you know which bulk feed lines are associated with the correct ink channel. This is very important! Hooking up a bag of ink to the wrong ink line will require you to flush the ink line with cleaning fluid before attaching the correct bag of ink.

### Epson R1800 Printer Ink Layout

- 1 Black = Dye Sub Black
- 2 Cyan = Dye Sub Cyan
- 3 Magenta = Dye Sub Magenta
- 4 Yellow = Dye Sub Yellow
- 5 Light Black = MultINK Black
- 6 Light Cyan = MultINK Cyan
- 7 Light Magenta = MultINK Magenta
- 8 LIGHT LIGHT Black = MultINK Yellow

**NOTE:** Please check with your distributor to make sure that you know which bulk feed lines are associated with the correct ink channel. This is very important! Hooking up a bag of ink to the wrong ink line will require you to flush the ink line with cleaning fluid before attaching the correct bag of ink.

## Epson 4800 / 4880 Printer Ink Layout

- 1 Black = Dye Sub Black
- 2 Cyan = Dye Sub Cyan
- 3 Magenta = Dye Sub Magenta
- 4 Yellow = Dye Sub Yellow
- 5 Light Black = MultiINK Black
- 6 Light Cyan = MultiINK Cyan
- 7 Light Magenta = MultiINK Magenta
- 8 LIGHT LIGHT Black = MultiINK Yellow




### Slots / Ink Type

- Slot #1 - Epson Black - Dye Sub Black
- Slot #2 - Epson Cyan - Dye Sub Cyan
- Slot #3 - Epson Magenta - Dye Sub Magenta
- Slot #4 - Epson Yellow - Dye Sub Yellow
- Slot #5 - Epson Light Black - MultiINK / CB Black
- Slot #6 - Epson Light Cyan - MultiINK / CB Cyan
- Slot #7 - Epson Light Magenta - MultiINK / CB Magenta
- Slot #8 - Epson Light Light Black - MultiINK / CB Yellow


## Epson 7800, 7880, 9800 & 9880 Printer Ink Layout

- 1 LIGHT LIGHT Black = MultiINK Yellow
- 2 Light Magenta = MultiINK Magenta
- 3 Light Cyan = MultiINK Cyan
- 4 Light Black = MultiINK Black
- 5 Dark Black = Dye Sub Black
- 6 Dark Cyan = Dye Sub Cyan
- 7 Dark Magenta = Dye Sub Magenta
- 8 Yellow = Dye Sub Yellow



### Slots / Ink Type

- Slot #1 - Epson Light Light Black - MultiINK Yellow
- Slot #2 - Epson Light Magenta - MultiINK Magenta
- Slot #3 - Epson Light Cyan - MultiINK Cyan
- Slot #4 - Epson Light Black - MultiINK Black
- Slot #5 - Epson Black - Dye Sub Black
- Slot #6 - Epson Cyan - Dye Sub Cyan
- Slot #7 - Epson Magenta - Dye Sub Magenta
- Slot #8 - Epson Yellow - Dye Sub Yellow



**Slots / Ink Type**

- Slot #1 - Epson Light Light Black - MultiINK Yellow
- Slot #2 - Epson Light Magenta - MultiINK Magenta
- Slot #3 - Epson Light Cyan - MultiINK Cyan
- Slot #4 - Epson Light Black - MultiINK Black
- Slot #5 - Epson Black - Dye Sub Black
- Slot #6 - Epson Cyan - Dye Sub Cyan
- Slot #7 - Epson Magenta - Dye Sub Magenta
- Slot #8 - Epson Yellow - Dye Sub Yellow